

# PiCGENIE<sup>123</sup>®



### INSTRUCTIONS-OPTION 2

Installing Atomic Anchor in drywall with stud in behind wall.

**1.** Make pilot hole in mark Accu-Hanger bracket tip made on wall.



**2.** Remove nail



**3.** Cut or break off tip on Atomic Anchor.



**4.** Using your fingers, screw Atomic Anchor straight into drywall.



NOTE:

Our 50# 4-Pack kit includes large diameter nails to use for this procedure.

# PiCGENIE<sup>123</sup>®

*Picture Hanging Made Easy!*